

Thermal Printer User's Manual

**2824
2844**



Zebra Technologies Corporation

User's Manual No. 980381-001 Rev. A

©2002 ZIH Corp.

FOREWORD

This manual provides installation and operation information for the 2824 and the 2844 series printers, manufactured by Zebra Technologies Corporation, Camarillo, California.

COPYRIGHT NOTICE

This document contains information proprietary to Zebra Technologies Corporation. This document and the information contained within is copyrighted by Zebra Technologies Corporation and may not be duplicated in full or in part by any person without written approval from Zebra Technologies Corporation. While every effort has been made to keep the information contained within current and accurate as of the date of publication, no guarantee is given or implied that the document is error-free or that it is accurate with regard to any specification. Zebra Technologies Corporation reserves the right to make changes, for the purpose of product improvement, at any time.

TRADEMARKS

LP 2824, TLP 2824, LP 2844 and TLP 2844 are service marks of Zebra Technologies Corporation. Windows and MS-DOS are registered trademarks of Microsoft Corp. All other marks are trademarks or registered trademarks of their respective holders.

LP 2824, TLP 2824, LP 2844 and TLP 2844 Thermal Printers



European Council Directive		Compliance to Standards	
89/336/EEC	EMC Directive	EN 55022-B 1998	RF Emissions control
	EMC Directive	EN 55024 1998	Immunity to Electro-magnetic Disturbances
92/31/EE	EMC Directive	EN 61000-3-2	Harmonic Emissions
92/31/EE	EMC Directive	EN 61000-3-3	Voltage Variation
	CB Scheme	EN 60950 1991 A1, A2, A3, A4	Safety

FCC - DECLARATION OF CONFORMITY:



Models: LP 2824, TLP 2824, LP 2844 and TLP 2844 conform to the following specification:
FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109(a) Class B digital device

Supplemental Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following Two Conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INDUSTRY CANADA NOTICE:

This device complies with Industry Canada ICS-003 class B requirements.

Cet équipement est conforme à l'ICS-003 classe B de la norme Industrielle Canadian

WE NEED TO HEAR FROM YOU

We Need To Hear From You!

**To Establish Your Warranty Period And Provide Access To Technical Support,
Send Us Your Product Registration Card Today!**

To establish your warranty period and provide access to technical support, send us your product registration card today.

RETURN MATERIALS AUTHORIZATION

Before returning any equipment to Zebra for in warranty or out of warranty repair, contact Repair Administration for a Return Materials Authorization (RMA) number. Repack the equipment in the original packing material and mark the RMA number clearly on the outside. Ship the equipment, freight prepaid, to the address listed below:

**Zebra RMA, USA
1001 Flynn Road
Camarillo, CA. 93012
Phone: +1 (805) 579-1800
repair@zebra.com**

**Label Printers:
Zebra Technologies, Europe
Zebra House
The Valley Centre, Gordon Road
High Wycombe
Buckinghamshire HP13 6EQ, UK
Phone: +44 (0) 1494 472872
FAX: +44 (0) 1494 450103**

**Card Printers:
Zebra Technologies, Europe
Zone Industrielle, Rue d'Amsterdam
44370 Varades, France
Phone: +33 (0) 240 097 070
FAX: +33 (0) 240 834 745**

**SHOCK HAZARD WARNING:**

The printer and power supply should never be operated in a location where either one can get wet. Personal injury could result.

**MEDIA AND RIBBON WARNING:**

Always use high quality, approved labels, tags and ribbons. If adhesive backed labels are used that DO NOT lay flat on the backing liner, the exposed edges may stick to the label guides and rollers inside the printer, causing the label to peel off from the liner and jam the printer. Permanent damage to the print head may result if a non-approved ribbon is used as it may be wound incorrectly for the printer or contain chemicals corrosive to the print head. Approved supplies can be ordered from your dealer.

**RELOADING HINT:**

If labels or ribbon run out while printing, DO NOT turn the power switch OFF (0) while reloading or data loss may result. The printer automatically restarts after you load a new label or ribbon roll.

**STATIC DISCHARGE:**

The discharge of electrostatic energy that accumulates on the surface of the human body or other surfaces can damage or destroy the print head or electronic components used in this device. DO NOT TOUCH the print head or the electronic components under the top cover.

**THERMAL PRINTING:**

The print head becomes hot while printing. To protect from damaging the print head and risk of personal injury, avoid touching the print head. Use only the cleaning pen to perform maintenance.

TABLE OF CONTENTS

Installation and Operation

Unpack Your Printer	2
Installation	4
Attach Power	4
Attach Interface Cable	5
Load Media	6
AutoSense Media Gap Sensing	9
Install Software	11
Operation	12

Using Options

Using Transfer Ribbon	14
Using the Label Dispenser	19
Using Fan-Fold Media	20
Using the Media Cutter	21

Troubleshooting

Problems and Solutions	23
Serial Interface Cable Wiring	26
Parallel Interface Cable Wiring	27
Universal Serial Bus (USB).	28
Cash Drawer Cable Wiring	28
Internal ZebraNet PrintServer II	29
Alternative Serial Interface Input	30
Cleaning the Print Head	31
Cleaning the Platen	32
Preparing Media, Paper, and Labels Before Loading	33

Installation and Operation

This section provides information on the installation and operation of the printer.


The printer is a low cost, desktop thermal printer. The printer is specifically designed for printing labels, tags or continuous receipts (with or without bar codes) from any DOS[™], Windows[™] or ASCII-based compatible host.

There are four models of printer. Many illustrations in this manual show the wide printer. While there are some physical differences among them, you can operate all printers using the same procedures.


Unpack Your Printer There are four models of printer. You have received one of these printers:

*Direct thermal
and thermal
transfer printing*

TLP 2824




TLP 2844




*Direct
thermal
printing*

LP 2824




2" (50.8mm)
printing

LP 2844




4" (101.6mm)
printing


**Additional
Accessories:**




Sample
Labels




Power
Cord





Cleaning
Pen



Software and
Documentation




Power
Supply



Installation The following steps will guide you through the installation of the printer and software.


Step 1 Attach Power Supply To The Printer

Power OFF




Check Voltage


**Plug in
Power
Module**



**Plug in
Power
Cord**




**Plug Power Cord
into a Suitable
AC Outlet**



See the SHOCK HAZARD WARNING on page iv.

Step 2 Attach Interface Cable



Step ③ Load Media




Open Cover


SHOW ME

LP 2844

TLP 2824 LP 2824



Open Guides




2824

Adjust Holders
1.0 inch
2.5 cm



SHOW ME

1.5 inch
3.8 cm




Load Media - continued

**Remove the outside
length of media**




**SHOW
ME**

For more information
on media preparation,
refer to Appendix A.




Install Roll

**Note: Find the
instructions for
preparing media in
Appendix A.**



Close Guides to the Width of the Media

**Note: When using
linerfree labels,
adjust the guides to
the widest position**



Load Media - continued




Release Cover


SHOW ME

TLP 2844 TLP 2824

*Note: This step
applies to thermal
transfer printers*



Close Cover




Step 4 AutoSense Media Gap Sensing




SHOW ME Perform this procedure when loading a new LP 2844 roll. If your printer has the label dispenser option, turn OFF the label taken sensor.

TLP 2824 LP 2824


Power OFF



**Hold
Feed Button**




Power ON



AutoSense Gap Sensor Adjustment - continued

**When Indicator
Flashes, Release
Feed Button**




**Printer Advances
Media and Prints
Status Summary**

**Note: Printer is in
diagnostic dump mode**

```
UKQ1935   16 V3.21
Serial port : 96,N,8,1
Image buffer size:1032K
Fmem:000.0K,016.4K avl
Gmem:000K,0593K avl
Emem:000K,0593K avl
I8,0,001  rY
S2 D10 R016,000 ZT UN
q800 Q01225,026
Option:
04 08 13
now in DUMP
```


**Tap Feed Button
To Begin Normal
Operation**

**Note: Printer prints
"out of DUMP"**



If the indicator remains orange or red, see the troubleshooting steps.

Step 5 Install Software



Start your computer and follow the installation instructions on the compact disc (CD).

Operation The following information helps you get the most from your printer.

Programming Commands You must use programming to control many of the printer's functions. See the EPL2 programmer's manual for details. For example, the **Q** command controls form length and gap.

Printer Driver The printer driver provides a convenient control to improve print quality. For example, Print density (darkness) is affected by the heat energy (density setting) applied and by the print speed. Changing both Print Speed and Density may be required to achieve the desired results.

Thermal Printing: Direct or Transfer? You must use the correct media for the type of printing you require. When printing without a ribbon, you must use direct thermal media. When using ribbon, you must use thermal transfer media. The printer's ribbon sensor detects motion of the supply spindle.

Replacing Supplies When replacing media or ribbon, do not turn off the printer or data loss occurs. The printer automatically resumes printing after you load new supplies.

2 ***Using Options***

This section provides information on the printer's optional features:

- thermal transfer printing
- label dispenser
- fan-fold media
- media cutter

Using Transfer Ribbon The TLP printer supports both direct thermal media (chemically treated to darken when heated) and thermal transfer media (accepts wax and/or resin transferred off a ribbon).


Step ❶ Prepare Ribbon



Pull Adhesive Strip Free


SHOW ME

TLP 2844 TLP 2824




Step 2 Install Supply Roll


***Thread
Ribbon
Through
Carriage***



***Press
onto Hub***




***Align Notches
onto Hub Spokes***




Step ③ Install Take-Up Core

***Press
onto Hub***



***Align Notches
onto Hub Spokes***




Step 4 Tighten Ribbon

Attach Ribbon to Take-Up Core


Notes:

*Align ribbon so
that it will be taken
straight onto core.*

*Use the adhesive
strip on new rolls;
otherwise, use
tape.*



Remove Slack From Ribbon



When using ribbon, make sure you also use thermal transfer media.


***Adding a New
Transfer Ribbon***

If ribbon runs out in the middle of a print job, the indicator lights orange and the printer waits for you to add a fresh roll. Keep the power on as you change ribbon. Open the top cover, then cut the used ribbon so you can remove the cores. Load a new ribbon roll (refer to the previous procedure if necessary). Close the top cover. Press the Feed button to restart printing.


***Replacing a
Partially Used
Transfer Ribbon***

To remove used transfer ribbon, cut the ribbon from the take-up roll. Remove the take-up roll and discard used ribbon. Remove the supply roll and tape the end of any fresh ribbon to prevent it from unwrapping. When reinstalling a partially used supply roll, tape the cut end onto the empty take-up roll.

***Cut Used
Ribbon
from Supply***



***Push Supply
Roll Out***



Using the Label Dispenser



SHOW ME


LP 2844

TLP 2824

LP 2824


*Open
Door*

*Switch On
the Label
Taken Sensor*




*Remove
Several
Labels*

*Push
Liner
Through
Slot*




*Close
Door*

*Close
Top Cover
and Press
Feed Button*



Using Fan-Fold Media


**Insert
Media**




**Adjust Holders
to Width of Media**

**2844—Tighten Screw
(use a small
Phillips driver #1)**


**2824—Lock Guides in
Place**



**Adjust Guides
to Width of Media**



Using the Media Cutter Printers that have a bezel with a motorized blade can dispense one or more forms that are then automatically cut from the media supply.



This option cuts through continuous paper from rolls and liner between labels.

Use the **OC** command to activate the cutter and the **Q** command to set the form length and gap distance. See the EPL2 programmer's manual.



Clearing the Media Cutter

If the blade cuts through labels, adhesive can jam the cutter.



Turn OFF (O) printer power and unplug the power and interface cables before clearing the cutter.

Keep the cutter dry. Never use any solutions or solvents to clean the blade.



After removing debris, plug in the power and interface cables, turn on the printer, then test for normal operation.

Appendix A - Troubleshooting



Problem	Solution or Reason
STATUS Indicator	
Does not light after turning ON (I) printer.	<ol style="list-style-type: none"> 1. Check power connections from A.C. outlet to power supply to printer. 2. Check that media or ribbon is present.
Blinks GREEN.	<ol style="list-style-type: none"> 1. Printer receiving data through interface. 2. Signal to begin AutoSense after turning ON printer. Release the FEED button.
Lights ORANGE.	<ol style="list-style-type: none"> 1. The optional cover open sensor is active. Press top cover to close and lock. 2. Printer has a syntax or command error. Check program and resend print job.
Blinks RED.	<ol style="list-style-type: none"> 1. Firmware download in process. Indicator lights red, then green.
Lights RED.	<ol style="list-style-type: none"> 1. Media or ribbon is out. Reload a new supply. 2. Power-up failure. 3. Printer ready to receive flash programming during firmware download.
Printer Operation	
Lights GREEN, but printer will not print.	<ol style="list-style-type: none"> 1. Check interface cable connections from computer to printer. 2. Make sure top cover is locked closed. 3. Check that labels are correct. 4. Verify media has print surface up for printing. 5. Check that transfer ribbon is correctly routed and has the ink side out for thermal transfer printing.

Problem	Solution or Reason
Printer Operation--continued	
Printer appears to be working (media is being fed out), but nothing is printed.	<ol style="list-style-type: none"> 1. Verify that the labels are the correct type. 2. Check that the roll is loaded with the direct thermal side facing up. 3. Clean the print head with cleaning pen. 4. Ensure top cover is locked closed.
Printing is faded or poor quality.	<ol style="list-style-type: none"> 1. Clean the print head with cleaning pen. 2. Adjust print speed/darkness in software. 3. Check the media and verify that print surface is facing up. 4. Check the correct combination thermal transfer ribbon and media are in use.
Prints only partial label or skips a label.	<ol style="list-style-type: none"> 1. Perform AutoSense gap sensor adjustment on page 9. 2. Label caught on print head. 3. Top cover is not properly latched. 4. Possible software problem. Check the printer memory configuration. Refer to the EPL2 Programming manual.
Printing stops and STATUS indicator lights ORANGE or RED.	<ol style="list-style-type: none"> 1. Perform AutoSense gap sensor adjustment on page 9. 2. Possible problem with label stock. Use only approved labels and tags. 3. Possible label jam. 4. Insufficient memory for label size. Check the printer memory configuration. 5. Possible software problem. Refer to the EPL2 Programming manual.

Troubleshooting Media Handling


Problem	Solution or Reason
Ribbon Path	
Evident wrinkles result in diagonal stripes on printout.	1. Make sure ribbon mounts straight onto take-up core.
Label Dispenser	
Printing continues between labels.	<ol style="list-style-type: none"> 1. Make sure label-taken sensor is on. 2. The label-taken sensor is blocked or dirty. Remove any scraps or dust. 3. Continuous media may be set. Verify form length setting through programming Q command. See the EPL2 programmer's manual.
Print one label and stops.	1. Verify the quantity has been correctly set.
Cutter Operation	
Blade cuts through labels instead of cutting liner between labels.	1. Verify form length setting through programming.
Media jammed in cutter.	1. Unplug power and interface cables. Use tweezers to remove scraps from cutter opening.
Media fails to cut direct thermal paper or label liner.	<ol style="list-style-type: none"> 1. Use programming C command to cycle cutter several times without media to perform a self-cleaning. See the EPL2 programmer's manual. 2. Cutter must be replaced.

Serial Interface Cable Wiring The figure below displays the cable wiring required to use the printer's RS-232 serial interface.



*+5 volts at 150 mA for external device (e.g. KDU or scanner)

Parallel Interface Cable Wiring The figure below displays the cable wiring required to use the printer's Centronics parallel interface.



Male DB-25 to Male Centronics (Cable)


+5 volts at 300 mA for external device (e.g. KDU or scanner)

Universal Serial Bus (USB) The table below provides the contact terminating assignments by number and electrical value for the cable connectors.

Contact Number	Signal Name	Typical Wiring Assignment
1	VBUS	Red
2	D-	White
3	D+	Green
4	GND	Black
Shell	Shield	Drain Wire

You can refer to the Universal Serial Bus Specification for details regarding this interface.

Cash Drawer Cable Wiring The figure below displays the pin assignments for the printer's retail cash drawer interface. Refer to the cash draw manufacturer's documentation for proper drawer wiring.





Male RJ-11

Internal ZebraNet PrintServer II (optional) This interface uses an RJ-45 straight-through cable type. The table below provides the pinout assignments.

Signal	Pin	Pin	Signal
Tx+	1	1	Tx+
Tx-	2	2	Tx-
Rx+	3	3	Rx+
---	4	4	---
---	5	5	---
Rx-	6	6	Rx-
---	7	7	---
---	8	8	---

For details regarding this interface and its operation, refer to the user guide supplied with your ethernet print server.

Alternative Serial Interface Input The pinout of the RJ-11 interface connector is listed below.



Note that looking into the printer's connector with the key notch pointing down, pins are numbered from left to right.

Cleaning the Print Head When you load new media, you can also clean the print head.




Turn OFF (O) the printer before performing this procedure.

***Rub
Cleaning
Pen Across
Dark Area
of Print Head***

***Wait
One Minute
Before Closing
Printer***

***Do Not Clean Roller
With Cleaning Pen***



SHOW ME

LP 2844

TLP 2824 LP 2824


Cleaning the Platen The platen, over time, picks up adhesive and dust which requires occasional cleaning.

To follow these steps, you require a clean, lint-free cloth lightly moistened with isopropyl alcohol.




Turn OFF (O) the printer before performing this procedure.

***Gently Wipe
Top of Platen***



***Advance Platen
One-Sixth (1/6) Turn
(about 60°)***



***Repeat Steps Until
Platen is Clean***


Let the platen dry for at least one minute before loading media.

Preparing Media, Paper, and Labels Before Loading

During shipment, the outside length of media may become dirty when handled or dusty when stored. A preparation before loading media makes sure both the print head and platen stay cleaner for more time.


Label Rolls

Find the tape and pull off both labels held by the tape




Tag Stock Rolls

Find the tape and detach the bottom tag



You must avoid dragging adhesive or dirty media between the print head and platen. Such an occurrence damages the print head and is not covered under your warranty.



980381-001A